

PIGMENTURA BY CHT

SETTING AN INNOVATIVE STANDARD FOR TEXTILE DYEING.

T

H

=

I

-

SMOOTH, DURABLE, AND EFFICIENT.

RESULT OF A RESEARCH ALLIANCE WITH INDITEX.

CHOOSE PIGMENTURA. IT IS EXCITING FOR YOUR CUSTOMERS, EASY ON YOUR WORKERS AND FRIENDLY TO OUR PLANET.

Sustainability has become a key factor in business these days. As the textile industry requires a vast amount of precious resources, we need to make sure that the value chains stay efficient but have a positive impact on the environment too.

With recent technological advances this is possible!

PIGMENTURA by CHT is a novelty, pigment based dyeing approach that is not only fast and easy to implement, but crucially requires no water for soaping and rinsing. Simultaneously, it outperforms older methods of pigment dyeing by achieving darker shades and increased color fastness and smoother hand feel thereby overcoming the old disadvantages of conventional pigment dying.

PIGMENTURA by CHT is a result of a research alliance between INDITEX and CHT.

We believe in **PIGMENTURA by CHT** as a lighthouse to navigate the exciting times ahead of the textile industry and all its stakeholders. To best serve our direct customers, the end users, and the environment we need to innovate boldly and rethink creatively. Whilst doing so we need to focus on openly exchanging knowledge and skills. Because in the end competition will not save the planet, cooperation will.



RECIPES

Product	Guideline	Pale Shades	Medium Shades	Dark Shades
KOLLASOL CDO	1 – 3 g/l	1 g/l	1 g/l	1 g/l
PIGMENTURA 1000	25 – 150 g/l	25 – 75 g/l	50 – 100 g/l	100 – 150 g/l
PIGMENTURA 2000	0 – 75 g/l	0 – 25 g/l	0 – 50 g/l	0 – 75 g/l
BEZAPRINT Pigments	x g/l	< 3 g/l	< 15 g/l	> 15 g/l

KEY ADVANTAGES OF PIGMENTURA

thanks to state-of-the-art textile chemistry

- Increased color fastness, levelness, and color spectrum thanks to a more powerful and crosslinking migration inhibitor
- Smoother hand feel thanks to the abandonment of classical binder technology
- **Ecologically sound** thanks to the avoidance of hazardous chemicals, such as formaldehyde, in accordance with major RSLs and standards; circularity
- Production benefits thanks to the sum of the chemical innovations
- no migration at the stenter pins, clips, or selvedges
- no film formation on padding rollers, stenter pins and clips
- easy and safe machine cleaning by simply rinsing with water
- new opportunities on existing equipment

PIGMENTURA BUILDS UPON PERKS OF CONTINUOUS DYEING WITH PIGMENT

Responsible with resources

- save up to **96%** of water compared to other continuous dyeing processes
- save up to 60% of total energy consumption that used to be wasted for heating water

Easy to implement

- **short** setup time
- highly **reliable** thanks to less complexity

One serves all

- even complex fiber blends are dyeable in a one-stepprocess
- only one dyeing process is required for a huge variety of textiles, particularly suitable for recycled materials
- your sustainable contribution to a circular economy

OUR PRODUCT PORTFOLIO


PIGMENTURA 1000

Crosslinking migration inhibitor with great compatibility for pigment dispersion. Product is not film-forming and ensures therefore great process stability, hand, and machine cleaning

PIGMENTURA 2000

Auxiliary to improve dry crock in continuous dyeing with pigments based on hydrophilic polymers with additives. Usually used only in combination with the migration inhibitor PIGMENTURA 1000 when needed.

RECOMMENDED BEZAPRINT PIGMENT DISPERSIONS








KOLLASOL CDO

Non-ionic deaerator and penetration accelerator with excellent foam-inhibiting properties and high compatibility with pigments and auxiliaries.

BEZAPRINT

Selected water-based pigment dispersions for high reproducibility and ecological safe products.

BEZAPRINT Red SGR BEZAPRINT Red KF **BEZAPRINT Pink BW BEZAPRINT Violet FB**



BEZAPRINT Blue BT BEZAPRINT Blue TB BEZAPRINT Brown B-RRT **BEZAPRINT Black DW**

PROCESS

- 1. Pad with low pick-up if possible
- **2.** Dry using a double-sided infrared dryer, if possible, in combination with a stenter
- 3. Cure at 160 °C for 3 min

Alternatively, drying on a finishing stenter is also possible if an infrared dryer is not available. In this case we recommend to lower air circulation in the first two chamber by at least 50% and use temperatures in the first chambers below 140 °C. In the last chambers higher temperatures and air circulation are possible.

FABRIC SELECTION

PIGMENTURA can be used on all substrates but is particularly suitable for cotton and cotton blends. We recommend using staple yarns whenever possible for best possible results.

PREPARATION OF THE PADDING LIQUID

- **1.** Add at least half of the required water into the mixer
- 2. Add KOLLASOL CDO
- 3. Add PIGMENTURA 1000
- 4. Add BEZAPRINT
- 5. Add the remaining water
- **6.** Stir for 5 minutes

For optimal process reliability, it is recommended to keep stirring the liquor during production.

APPLICATIONS

- Apparel
- Tablecloths
- Napkins
- Wallcoverings
- Blankets
- Curtains
- Bed sheeting



The data and information provided in this document are intended for use by persons possessing technical skills and knowledge in dyeing technologies and sustainability. While the data in this document is provided in good faith, to the best of INDITEX's knowledge and has been developed by companies that meet the highest industry standards based on various reliable sources, INDITEX does not commit to it being accurate, complete or updated (since data can quickly become out-of-date). Neither INDITEX nor any of its employees make any warranty, express or implied, including warranties of fitness for a particular purpose, or assume any legal liability or responsibility for the accuracy, completeness, or usefulness of any information provided (either isolated or in the aggregate form). While every effort is made to ensure the data quality, such data is provided "as is" and recipient expressly acknowledges that the data might contain some minor defects. Since INDITEX does not warrant that the data will meet the recipient's needs or expectations, the burden of fitness of the data relies completely on the recipient. Additionally, nothing arising from the data should be taken to constitute professional advice nor a formal recommendation. Therefore, INDITEX is not responsible for data management after extraction and transmission to the recipient. Thus, INDITEX will not be liable (to the fullest extent permitted at law) for any loss, damage or inconvenience arising out or in connection of the use of or the inability to use any information on the set of manuals".



III IIIII

Textile Auxiliary Solutions Printing and Flocking +49 7071 154 405 print-flock@cht.com

CHT Germany GmbH | Bismarckstraße 102 | D-72072 Tübingen

www.cht.com